

**TRUCKS 1/4 TON COMMAND RECONNAISSANCE LANDROVER  
RESECURING – REAR SEATS TO SIDE PANELLING**

**Summary**

1. This instruction details the resecuring of the rear seats to the side panelling by pop rivetting, to prevent further parting.
2. **Action Required.** Units and RAEME workshops affected are to note and observe this instruction.
3. **Stores Required.**

Sec/Cat No	Designation	Qty per Veh
G1/GAA 0171	Rivets, dome head, pop, monel metal, break stem, 3/16 in dia by 0.300 in	As required

**Detail**

4. Proceed as follows:
  - a. Drill holes on 3 in centres along side panels using a No 11 drill, and ensuring that:
    - (1) Holes are not drilled through existing spot welds.
    - (2) Hole centres are at least 3/8 in from edge of seat panel flange.
  - b. Install one 3/16 in pop rivet in each hole.

**END**