

CURRENT-VOLTAGE REGULATOR TYPE N41-285-39

UNIT REPAIRS

NOTE:- This instruction supersedes DEME Bulletin ELEC 2/61

INTRODUCTION

1. This instruction details the procedure when adjustment to regulator, fitted to 3/4 Ton FFW Landrover, is necessary.

PRECAUTION

2. Do not run the engine whilst the regulator is open circuited as damage to the rectifier will occur.

REPAIR INFORMATION

3. The regulator will be removed from the vehicle and all adjustments carried out on the bench. Only qualified tradesmen will attempt any repair or adjustment to this unit.

E N D